

しゃもじ・竹スプーン・竹トング



37-002-1
(23)
(竹杓子 大)
¥200



37-002-2
(21.5)
(竹杓子 中)
¥180



37-002-3
(18.5)
(竹杓子 小)
¥170



37-300
(13.5)
(竹杓子 豆)
¥130



30-146 ㊤
(20)
(スス竹杓文字 艶消)
¥700



30-148 ㊤
(29.5)
(スス竹炒飯ヘラ)
¥1,500



37-750 ㊤
(φ5×16)
(煮豆スプーン大)
¥800



37-902
(4.5×20.5)
(カレー Spoon)
¥300



37-200
(18)
(ジャムスプーン)
¥340



37-801
(15.5)
(バターナイフ)
¥100



37-751 ㊤
(φ4×14.8)
(煮豆スプーン小)
¥650



37-415 ㊤
(9.5)
(磨小判小白)
¥400



37-754 ㊤
(8)
(薬味サジ)
¥300



37-505 ㊤
(30)
(天ぷらばさみ)
¥1,020




37-503 ㊤
(18)
(晒アイストング)
¥870



37-504 ㊤
(18)
(曲がりトング)
¥870



37-502 ㊤
(12)
(ミニトング)
¥490



37-501 ㊤
(10)
(ミニトング 小) ¥440



37-109
(6×30)
(ターナー)
¥200



37-008
(6.5×30.5)
(穴あきターナー)
¥200



37-107
(6.5×30.5)
(ターナーカット)
¥190



30-147 ㊤
(30)
(スス竹ターナー 艶消)
¥1,000

廃番